
## ToughArmor EX










Package Contents。 Packungsinhalt。 Contenu。 Contenido del paquete 。 包装について。 包装説明。 包装说明



User Manual









Key x 2

Device Information ® Geräteinformationen ® Informations dispositif ® Información del dispositivo ® 本体説明 ® 機體說明 ® 机体说明











3-3


3-7




3-4



Unlocked




Rotate the thumb screw counterclockwise to release the handle of the 2.5" drive tray.



Please use the included M3\*4 flat

head screws only.



88888

diminish over time.

. o (b)

Head Screws

 Remove the protective layer from the 3M adhesive and affix the MB491SKL-1B to your chosen external 3.5" bay location on the case.  $\mathbb{L}$ M3\*4 Pan

Aurini e

- 2. Insert the MB491SKL-1B into a 3.5" drive bay and use the included M3\*4 pan head screws to secure the MB491SKL-1B.
  3. Connect the 15-Pin SATA power and SATA 7-Pin cables to the MB491SKL-1B to complete installation. Please note that the water-resistant function only applies to the water-resistant cover (Tough-Cover) of the MB491SKL-1B. The device itself does not have water-resistant function. The main function of this design is to prevent low-pressure water from entering the device through the water-resistant cover. To ensure the device is properly installed, please make sure the system chassis where the MB491SKL-1B is installed has a flat and smooth surface around the 3.5" device bay to prevent water from entering the device or system through uneven surfaces.
- We recommend using a wide-temperature HDD/SSD with the MB491SKL-1B to ensure the drive's operation is not affected by extreme temperatures.

ICY DOCK reserves the right to change product specifications, components, or accessories without prior notice. For warranty information, please visit www.icydock.com/warranty.php